


# EXPANDER® TOOLING

**ADJUSTABLE SLIDE HAMMER & ADAPTER KITS** 





# **AVAILABLE KITS WITH CASE**

# **EXPANDER SYSTEM SLIDE HAMMER**

# **SMALL KIT**

**Article #**641317

Slide weight alterations: 1,6 - 2,7 - 4,3 kg Length alterations: 350 - 775 mm Total weight incl. case: 10 kg



Slide weight 2,7 kg #206439 Extra weight 1,6 kg #206440 Rod 300 #209359

Rod 300 #209359



Handle incl. lifting eye #209361 & #224372



# Thread adapters

**|-**

M20x1,5 #209484



M24x3 #209513





M30x2 #209485



M24x2 #209483



M36x3 #209519

# **EXPANDER SYSTEM SLIDE HAMMER**

# **LARGE KIT**

Article #643838

**Slide weight alterations:** 2,5 - 5,0 - 7,5 kg **Length alterations:** 350 - 550 - 975 mm

Total weight incl. case: 17 kg











Slide weight XL 5,0 kg #206463 Extra weight XL 2,5 kg #206464 Rod 500 #209360 Hammer stop #209528 Multi adapter #209529



Rod 300 #209359



Handle incl. lifting eye #209361 & #224372



Stop nut #209435

Thread adapters



M20x1,5 #209484



M24x3 #209513



M30x3,5 #209560



M20x2,5 #209570

M24x2

#209483



M30x2 #209485

M36x3

#209519

M #

M42x3 #209563

# Hammer tips



Chisel #209524



Cotter pin removal #209530



Pin Driver 6 mm #209526



Pin Driver 11 mm #209558



Pin Driver 21 mm #209525



Pin Driver 40 mm #209527

# **EXPANDER SYSTEM SLIDE HAMMER**

## **YI KIT**

**Article #**643117

Contains everything from LARGE KIT plus:

# Sleeve installation and removal kit

for M16 #643706

# Multibolt adapters

For M16 95-114 #209396 For M16 115-184 #209397 Slide weight alterations: 2,5 - 5,0 - 7,5 kg
Length alterations: 350 - 550 - 975 mm
Total weight incl. case: 21 kg

# **HANDLE PINS AND SLEEVES WITH EASE**

By design, Expander System pivot pins are simple to install and remove with standard tools, thanks to the tapered axle and expanding sleeves. With the Expander System Slide Hammer, it's even faster and more controlled to remove the pins and sleeves, especially when working with larger pin systems.

The controlled shock force created by the sliding weight ensures safe and easy removal of pins and sleeves. The slide hammer can both push and pull to loosen even the most seated pins and sleeves. Together with the pin drivers and other hammer tips the slide hammer can be used as a linear sliding sledge to remove various pins, sacrificing teeths, cotter pins or to safely hammer on any other part.

# Safety features

The part to be removed is secured to the slide hammer. The handle has a lifting eye that can be used to prevent the parts from dropping. The slide hammer uses a controlled linear force, pulling away from the machine or pushing towards it locked to the part.

# **SLEEVE INSTALLATION AND REMOVAL KIT**

# FOR SLEEVES AND WASHERS WITH INCLUDED JACKBOLT THREAD.

**Article #**643704 for M16 (included in #643117)

**Article #**643705 for M20 Article #643706 for M24





# Kits include 4 Jackbolts & 2 guidebolts







# **SINGLE THREAD ADAPTER KIT**

Article #643840

#224443 Case

#209582 M16x1,5

#209580 EX M30x1,5

#209579 EX M20x1,5

#209578 EX M16x2

#209577 EX M16x1,5

#209576 EX M14x2 #209569 M16x2

#209568 M14x2

#209567 EX M12x1

#209566 EX M20x2,5

**ASK US FOR OTHER OR CUSTOM MADE ADAPTERS** FOR YOUR APPLICATIONS

# HAMMER KIT

Article #643841



Chisel #209524



Cotter pin removal #209530 & nut #206372



Pin Driver 6 mm #209526



Pin Driver 11 mm #209558



Pin Driver 21 mm #209525



Pin Driver 40 mm #209527



Rod 200 #209575



Multi adapter #209529



Hammer stop #209528

# **EXAMPLE OF MULTIBOLT ADAPTERS**




For M16 95-114 #209396




For M16 115-184 #209397 (included in 643117)

# EXPANDER SYSTEM SLIDE HAMMER HOW TO USE





# **EXAMPLE OF DIFFERENT USE CONFIGURATIONS:**



# Expander System Sweden AB Tel: +46 (0) 120 29900

Email: expander@nord-lock.com www.expandersystem.com

# Expander Americas, Inc.

Tel: +1 888 935-3884 Email: expander.us@nord-lock.com www.expandersystem.com

